

Coffee Maker

Sun Rental Center
(440) 942 6106

Add professional equipment to your party.
Easy instructions to our popular items.

Operating Tips

1. Fill coffee maker to desired level with **COLD** water.
2. Add coffee according to manufacturer's recommendations or chart
Below
3. *Plug coffee maker into proper electrical outlet.*

Do Not Use Extension Cord

4. Remove coffee grounds when coffee has finished brewing.

Note: One pound of coffee is equal to 4.75 cups of ground coffee.

Brewing Time (approximate)

30-60 cups	60 minutes
90-100 cups	90 minutes

Coffee Equivalents

Number of cups	Coffee Measure
30	2 cups
55-60	3 1/2 cups
90	6 cups

Last note:

We suggest that one person be designated to operate this equipment. This will make for a safe and enjoyable party. If any questions, please ask one of our associates.

UNDERSTAND YOUR RENTAL CONTRACT/KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

These guidelines and tips are common-sense suggestions designed to promote coffee machine efficiency and safety. Compiled from literature of leading experts in the field, they are believed to be reliable, and are offered as suggestions and illustrations to deal principally with common practices and conditions encountered in the use of coffee machines. The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplant or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate.

Accordingly,
The Sun Rental Center disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.