

MINI HOT DOG CART

OPERATING INSTRUCTIONS

This unit is designed to be used with water in the pan liner. The water will give a better distribution of heat and help keep food from drying out. This unit is not designed for cooking foods but to keep hot foods at a desired temperature for serving.

WET OPERATION WITH COVER

1. Fill the bottom of the well with $\frac{1}{2}$ " to $\frac{3}{4}$ " of hot water and cover top opening. (HOT water at set up will reduce the total preheat time.)
2. Set the control dial to the highest position for 30 minutes with well covered to preheat unit. Once the unit is up to operating temperature, add the precooked/preheated food product to pans.
3. Adjust to desired setting for food temperature.
4. Dial setting will vary with the type of food and individual serving temperatures.
5. Food pans should be covered to maintain temperature when food is not being served.

The above instructions are starting up instructions only and may be changed to suit your individual needs.

DO NOT LET UNIT RUN DRY!!! FAILURE TO KEEP WATER IN UNIT WILL AFFECT THE PERFORMANCE OF UNIT.

DO NOT IMMERSE COMPLETE UNIT IN WATER.

WASH PANS AND LIDS ONLY. USE SOAP AND WATER.