

PARTY CANOPY SET UP INSTRUCTIONS:

1. LAY OUT PARTY TENT TOP IN POSITION YOU DESIRE.
2. DRIVE STAKES SIX FEET OUT FROM TENT, TWO FOR EACH CORNER AND ONE BETWEEN CORNERS.
3. TIE GUY LINES TO STAKES LEAVING 3 ½' OF SLACK
4. PUT UP CORNER POLES. ADJUST ALL CORNER GUY LINE TIGHT.
5. PLACE CENTER POLE IN POSITION.
6. PUT UP WALL POLES BETWEEN CORNERS. ADJUST ALL GUY LINES.