



**Party Rentals & Sales**  
**Construction Equipment**  
**Homeowner Tools**  
**Public Storage**  
**440.942.6106**

**WWW.SUNRENTAL.COM**

## Instructions

# MINI HOTDOG CART

### Operating Instructions

- Fill the bottom of the well with 1/2 - 3/4 inches of hot water.
- Preheat the unit by setting the control dial to the highest setting for 30 minutes with the well covered.
- Once the unit has been preheated, add the precooked/preheated food and adjust the temperature accordingly.
- Cover food pans when not serving in order to retain the heat.

### Cleaning Instructions

- Remove all pans and lids and wash with soap and water.
- Do not immerse unit in water.
- Do not attempt to take apart the unit.

### Helpful Hints

- Do not let the unit run dry. This will cause damage to the unit.
- This unit is not designed to cook or preheat food. It is designed to keep food warm.

UNDERSTAND YOUR RENTAL CONTRACT / KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplement or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Sun Rental Center Inc disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.

Copyright © 2010 Sun Rental Center Inc. - Party - Tools - Storage