



Party Rentals & Sales
Construction Equipment
Homeowner Tools
Public Storage
440.942.6106

WWW.SUNRENTAL.COM

Instructions

POPCORN MACHINE

Operating Instructions

- Turn on kettle heat switch.
- Turn on kettle motor switch.
- Turn on exhaust switch.
- Open the popcorn packet and squeeze the contents into the kettle.
- When popcorn has popped, turn handle down to dump popcorn.
- Repeat cycle until the desired amount of popcorn has been reached.
- On the final batch of popcorn, turn the kettle heat switch when the popcorn breaks the top of the lid. This prevents the kettle from burning and smoking.
- Turn off all switches after complete.

Cleaning Instructions

- Allow kettle to cool until warm enough to handle.
- Unplug kettle and remove from machine.
- Wipe kettle, kettle lids, crossbar and exterior clean.
- Do not immerse kettle in water!!!
- Remove popped corns.
- Remove the "old maid" pan; empty un-popped kernels and wipe clean.
- Wipe interior of machine clean.
- Return the machine clean to the rental center to avoid cleaning charges.

Helpful Hints

- Do not touch kettle while operating. It is very hot!!!
- Air vents must be unobstructed to allow for proper air flow.

UNDERSTAND YOUR RENTAL CONTRACT / KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplement or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Sun Rental Center Inc disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.

Copyright © 2010 Sun Rental Center Inc. - Party - Tools - Storage