



INSTRUCTIONS: PATIO HEATER

Securing Top to Heater

1. Line up the three studs, on top of heat element, to the holes on round patio heater top
2. Attach with the three wing nuts provided. Be careful not to over tighten wing nuts. If wing nuts are too tight, it will cause damage to the heater top.

Connecting Propane to Heater

1. Open bottom storage compartment by lifting up storage sleeve
2. Set propane tank inside
3. Connect propane coupler by turning clockwise
4. Open valve
5. If you think there is a gas leak, spray soapy water on top of gas valve to see if there is a leak (you will see bubbles forming / possible rotten egg smell if there is a leak)

To Turn On the Heater

1. Turn the control knob to the "OFF" position
2. Open the LP cylinder gas valve fully
3. Push in, and turn the control knob to "HI" position (counter clockwise 90°)
4. Hold in the control knob for 3-5 seconds. While you continue to hold in the control knob, press the igniter button several times until the flame ignites
5. Hold the knob for 30 seconds or up to 2 minutes, and then release. **NOTE:** If the flame does not light or it goes out, repeat steps 3-5 above
6. To decrease the flame, turn the control knob towards LO. To increase the flame, turn the control knob to HI.

To Turn Off the Heater

1. Turn the control knob to "HI" position
2. Push in, and turn the control knob to the "OFF" position