



Party Rentals & Sales
Construction Equipment
Homeowner Tools
Public Storage
440.942.6106

WWW.SUNRENTAL.COM

Instructions

PROPANE GRIDDLE

Operating Instructions

- Make certain that the burner control valve/knob is in the Lock Off position.
- Attach a 14.1 or 16.4 oz propane cylinder to the regulator by sliding upward into the regulator inlet. Carefully engage the threads by pushing cylinder straight up and turning. Tighten hand tight only. Do not use tools of any kind.
- Rotate control knob to the Off position, depress and turn to the High position. Light all four corners of the burner. Replace griddle plate. Make sure the burner is lit.
- To turn off: Rotate control knob to the Off position, allow it to spring upward, then rotate to the Lock Off position.
- Be sure to turn off before replacing an empty propane cylinder. Always remove propane cylinder before storing or transporting the unit.

Cleaning Instructions

- Clean the griddle plate by scouring with plastic or steel wool scouring pads.
- Never immerse the burner, base or regulator in any solution.
- Clean by wiping with a damp cloth.

Helpful Hints

- A frost accumulation on the propane cylinder is normal and does not indicate a malfunction.
- Use caution in handling and using propane gas. Gas allowed to escape can result in a fire or explosion. It is heavier than air and may settle in the fire box, on floors, etc.
- Do not permit the unit to be operated without competent adult supervision.
- Do not leave the griddle unit unattended while operating. Check periodically to see that all four corners of the burner are ignited.
- If the flame goes out- shut off the gas valve immediately and allow gas to dissipate several minutes before relighting.
- Do Not operate a unit that is obviously damaged. Use only 14.1 or 16.4 oz disposable cylinders. Do not use adaptors to connect the units to a larger refillable cylinder.
- Remove the propane cylinders whenever the unit is moved or is not being used.

UNDERSTAND YOUR RENTAL CONTRACT / KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplement or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Sun Rental Center Inc disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.

Copyright © 2010 Sun Rental Center Inc. - Party - Tools - Storage