



Party Rentals & Sales
Construction Equipment
Homeowner Tools
Public Storage
440.942.6106

WWW.SUNRENTAL.COM

Instructions

SNOKONE MACHINE

Operating Instructions

- Start the motor and fill gooseneck an inch from the top with ice cubes or 3" or 4" pieces of ice. (The larger the ice pieces, the better the snow.)
- Push ice down against cutter head with firm pressure for best snow (too much = coarse ice; too little = mushy).
- DO NOT force the handle.
- Put only ice in the gooseneck to prevent damage to the blades.
- Keep fingers away from shaver body when motor is running to prevent injury.

Cleaning Instructions

- Unplug the machine.
- Wipe all surfaces clean.
- Rinse out syrup pumps.

Helpful Hints

- The machine includes a 110 volt, single phase, 60 cycle, AC current motor with toggle switch, shaving unit, dispensing case, and separate light switch inside the case.
- A cutter head is mounted on the end of the motor shaft inside the shaver body (gooseneck).
- The pusher handle presses the ice against the revolving cutter head to produce the shaved ice.

UNDERSTAND YOUR RENTAL CONTRACT / KNOW YOUR RESPONSIBILITY FOR THE EQUIPMENT YOU HAVE RENTED

The guidelines are not intended to be all-inclusive, complete descriptions of safe practices, or to supplement or replace other additional precautionary measure to cover usual or unusual conditions or situations where common sense might otherwise dictate. Accordingly, Sun Rental Center Inc disclaims all liability for, and makes no warranty or guarantee, the accuracy or applicability of this information in any situation.

Copyright © 2010 Sun Rental Center Inc. - Party - Tools - Storage